

Solutions for Dash Fundamentals Assignment

Exercise A: incorporate the dataset `shades.csv` into your app. And create the following layout in one app file:

1. A [Dropdown](#) that uses the column `brand` as the dropdown options. Make sure the brand names are unique (do not repeat themselves). Then, assign “Revlon” as the initial value.

Python

```
from dash import Dash, dcc, html
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades.csv')
app = Dash(__name__)

app.layout = html.Div([
    dcc.Dropdown(options=df.brand.unique(), value="Revlon")
])

if __name__ == '__main__':
    app.run(debug=True)
```

2. A [RadioItems](#) component in which the values from the column named `group` are assigned to the `options` property. The options should be unique and sorted from 0 to 7.

Python

```
from dash import Dash, dcc, html
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades.csv')
app = Dash(__name__)

app.layout = html.Div([
    dcc.Dropdown(options=df.brand.unique(), value="Revlon"),
```

```

        dcc.RadioItems(options=sorted(df.group.unique()))
    ])

    if __name__ == '__main__':
        app.run(debug=True)

```

3. Update the `options` property of the [RadioItems](#) component so that the `values` (of the options) represent numbers from 0 to 7, but the `labels` are their respective strings ([see Readme-shades](#) for the strings).

```

Python
from dash import Dash, dcc, html
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades
.csv')
app = Dash(__name__)

app.layout = html.Div([
    dcc.Dropdown(options=df.brand.unique(), value="Revlon"),
    dcc.RadioItems(options=[{"label": "Fenty Beauty's PRO FILT'R Foundation Only", "value": 0},
                           {"label": "Make Up For Ever's Ultra HD Foundation Only", "value": 1},
                           {"label": "US Best Sellers", "value": 2},
                           {"label": "BIPOC-recommended Brands with BIPOC Founders", "value": 3},
                           {"label": "BIPOC-recommended Brands with White Founders", "value": 4},
                           {"label": "Nigerian Best Sellers", "value": 5},
                           {"label": "Japanese Best Sellers", "value": 6},
                           {"label": "Indian Best Sellers", "value": 7}])
])

if __name__ == '__main__':
    app.run(debug=True)

```

Exercise B: using the same `shades.csv` create another app that incorporates Dash AG Grid into the layout:

1. The [Dash AG Grid](#) should represent the complete dataset with all its columns.

Python

```
import micropip
await micropip.install("dash_ag_grid")
from dash import Dash, dcc, html
import dash_ag_grid as dag
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades.csv')
app = Dash(__name__)

grid = dag.AgGrid(
    id="my-table",
    rowData=df.to_dict("records"),
    columnDefs=[{"field": i} for i in df.columns]
)

app.layout = html.Div([grid])

if __name__ == "__main__":
    app.run(debug=True)
```

2. Using [Pagination](#), add automatic pagination to Dash AG Grid and make sure all columns fit into the screen with no horizontal scroll bar (using the `columnSize` property).

Python

```
import micropip
await micropip.install("dash_ag_grid")

from dash import Dash, dcc, html
import dash_ag_grid as dag
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades.csv')

app = Dash(__name__)

grid = dag.AgGrid(
    id="my-table",
    rowData=df.to_dict("records"),
```

```

columnDefs=[{"field": i} for i in df.columns],
columnSize="sizeToFit",
dashGridOptions={"pagination": True, "paginationAutoPageSize": True},
)

app.layout = html.Div([grid])

if __name__ == "__main__":
    app.run(debug=True)

```

Exercise C: using the same [shades.csv](#) create a new app, where the layout has two new [Dash Core Components](#) that you haven't used so far.

There is no solution to exercise C. The goal is to choose whichever components you prefer to practice with.

Exercise D: using the following [scatter plot example](#), add a scatter plot to your app that displays **V** (value/brightness) on the x-axis and **S** (saturation) on the y-axis.

Clue: to display the plot in the layout, remember to assign your plot to the **figure** property of the dcc.Graph, for example: `dcc.Graph(figure=my_scatter_plot)`

```

Python
from dash import Dash, dcc, html
import plotly.express as px
import pandas as pd

df =
pd.read_csv('https://raw.githubusercontent.com/plotly/datasets/master/Dash-Course/makeup-shades/shades.csv')

app = Dash(__name__)

fig = px.scatter(df, x='V', y='S')

app.layout = html.Div([dcc.Graph(figure=fig)])

if __name__ == "__main__":
    app.run(debug=True)

```